



WARNING *Risk of Fire or Electric Shock*


- Turn OFF power at circuit breaker or fuse and test that the power is OFF before wiring.
- To be installed and/or used in accordance with appropriate electrical codes and regulations.
- If you are not sure about any part of these instructions, consult a qualified electrician.
- Use this device only with copper or copper clad wire.
- INDOOR USE ONLY

OVERVIEW

Intermatic's IOS-DOV-D-WH PIR technology 0-10 V dimming occupancy sensor can turn lights ON and OFF based on occupancy and allow the user to increase or decrease the lighting level.

SPECIFICATIONS

Input Voltage	120-277 VAC, 50/60 Hz
Electronic Ballast (LED)	600 VA, 120 VAC; 1385 W, 277 VAC
Tungsten	1000 W, 120 VAC; 1385 W, 277 VAC
Standard Ballast	660 VA, 120 VAC; 1100 VA, 220 VAC; 1520 VA, 277 VAC
Class 2 Dimming Output	0-10 VDC, 120 mA maximum current sink
General Use	12 A, 120-277 VAC
Resistive	10 A, 125/250/277 VAC
Motor	1/6 HP, 120/240 VAC
Coverage	PIR: up to 35 ft. (10.66 m)



LED Indicators

- Red LED Blinking: PIR sensor detects motion

Manual Up / Down Buttons:

- To turn ON the light, press the up arrow when the light is OFF. To turn OFF the light, press the down arrow when the light is ON.
- To adjust the light level, Press and hold the up arrow to increase light level and release at desired light level. Press and hold the down arrow to decrease light level and release at desired light level.

INSTALLATION

1. Always switch OFF the Electrical power before installing the sensor and make sure the sensor ratings are appropriate for the luminaire being controlled.
2. Wire the sensor according to the wiring diagram. (Refer To Diagram 1)
3. Attach sensor to junction box with 2 screws. (Refer To Diagram 2)
4. Attach Panel cover and wall plate. (Refer To Diagram 2)

Diagram 1 - Wiring Diagram




Diagram 2 - Installation





Diagram 3 - Traveler Wiring Diagram



DIP SWITCH PROGRAMMING

Time Delay

Time Delay: The time delay setting assigns the duration for the lighting to stay ON after no movement is detected. The time delay is controlled by DIP switches 1 through 3. Refer to the following table to set the time delay.

Time Delay	DIP1	DIP2	DIP3
30 sec	Off	Off	Off
2 min	On	Off	Off
4 min	Off	On	Off
8 min	On	On	Off
10 min	Off	Off	On
15 min - Default	On	Off	On
20 min	Off	On	On

30 min	On	On	On
--------	----	----	----

Occupancy and Vacancy Mode Selection (DIP 4)

Use DIP 4 to select Occupancy or Vacancy mode

DIP Switch	Mode
ON	Occupancy (Auto On)
OFF	Vacancy (Manual On)

Dimmer Synchronization (DIP 5)

The DIP 5 controls the Dimmer Synchronization mode when the multi-way function (Diagram 3) is used. If you turn DIP 5 ON, the second sensor can turn the light fixture ON/OFF and control the dimming light level. If you turn DIP 5 OFF, the second sensor can only turn the light ON/OFF. *(If using one sensor, leave the setting in the ON position)*

Walk-Through Mode (DIP 6)

Turn DIP 6 ON to enable “walk through mode”. In this mode, the load will be turned ON for 2 minutes when motion is detected. If no motion is detected after 90 seconds, the load will be turned OFF 30 seconds later. If a motion is detected after 90 seconds, the load will refer to the Time delay setting.


Ambient Light Level (DIP 7)

To set the ambient light level, turn ON DIP 7 and wait for 30 seconds for the light level to calculate the current ambient light in the room. Once programmed, If there is greater ambient light than the setting the light will not turn on. If there is less ambient light than the setting the light will activate.

N/A (DIP 8)

Not Applicable for this model.

PIR SENSITIVITY AND MODE SELECTION



PIR Sensitivity

Turn the variable resistor to adjust PIR sensitivity. It can be set from 60% to 100%.

Mode Selection

The mode selection switch is used to select ON, Auto or OFF mode

- ON: Lights Always ON
- Auto: Detection determines when the lights turn ON and OFF (Occupancy or Vacancy mode)
- OFF: Lights Always OFF

LIGHT LEVEL PROGRAMMING

High-Trim, Low-Trim and Initial On Light Level Activation Programming

Before setting the 3 light levels, you must enter the set/program mode. Put the mode selection switch to the OFF position and press the UP and Down button together. The sensor is in set/program mode when there is a solid Red LED illuminated. To pick which setting you would like to change click the up-arrow button until you see the Red LED blink in accordance to which setting you would like to change. (1 Blink – High-Trim, 2 Blinks – Low-Trim, 3 Blinks - Initial On Level)

A. High-Trim Setting:

When the Red LED flashes one time per period, press the “up” and “down” button together to start to set the High-Trim level. Click the **up arrow** the number of times in accordance with the chart below for your desired setting. Once complete press the “up” and “down” button’s together to save. If complete with all programing needs return sensor to auto mode.

High End Trim	Number of clicks on Up Arrow ↑ to set
80%	1- ↑ click
90%	2- ↑ click
100%	3- ↑ click -Default

B. Low-Trim Setting:

When the Red LED flashes two times per period, press the “up” and “down” button together to start to set the Low-Trim level. Click the **down arrow** the number of times in accordance with the chart below for your desired setting. Once complete press the “up” and “down” button’s together to save. If complete with all programming needs return sensor to auto mode.

Low End Trim	Number of clicks on Down Arrow ↓ to set
10%	1- ↓ click -Default
20%	2- ↓ click
30%	3- ↓ click

C. Initial On Activation Light Level Setting:

When the Red LED flashes three times per period, press the “up” and “down” button together to start to set the Initial On Activation Light level. Click the **up arrow** the number of times in accordance with the chart below for your desired setting. Once complete press the “up” and “down” button’s together to save. If complete with all programming needs return sensor to auto mode.

Initial On Activation Level	Number of clicks on Up Arrow ↑ to set
10%	1- ↑ clicks
20%	2- ↑ clicks
30%	3- ↑ clicks
40%	4- ↑ clicks
50%	5- ↑ clicks - Default
60%	6- ↑ clicks
70%	7- ↑ clicks
80%	8- ↑ clicks
90%	9- ↑ clicks
100%	10- ↑ clicks

NOTE: You cannot program the initial on activation light level setting below the selected Low-Trim or above the selected High-Trim. (Example: High-Trim is set at 90%. Initial On Activation cannot be higher than 90%, Low-Trim is set at 30%, Initial On Activation cannot be below 30%) (If error, LED will blink constant red)

D. Factory/Default Reset:

If you want to reset the sensor to factory settings, put the mode switch to the “ON” position and press the “Up” and “Down” arrows together and hold. The Red LED will flash 2 times and the sensor will reset to the factory/default settings. The factory/default settings are as follows: (High-Trim: 100%, Low-Trim: 10%, Initial On: 50%)

5-YEAR LIMITED WARRANTY

Warranty service is available by either (a) returning the product to the dealer from whom the unit was purchased or (b) completing a warranty claim online at www.intermatic.com. This warranty is made by: Intermatic Incorporated, Customer Service 1950 Innovation Way, Suite 300, Libertyville, IL 60048. For warranty service go to: www.Intermatic.com or call 815-675-7000.