

RAB Lighting is committed to creating high-quality, affordable, well-designed and energy-efficient LED lighting and controls that make it easy for electricians to instal and end users to save energy. We'd love to hear your comments. Please call the Marketing Department at 888-RAB-1000 or email: marketing@rablighting.com





HIDFA-205S-EX39-8CCT-BYP

IMPORTANT

READ CAREFULLY BEFORE INSTALLING LED HID BULBS. RETAIN THESE INSTRUCTIONS FOR FUTURE REFERENCE.

RAB LED HID Bulbs must be wired in accordance with the National Electrical Code and all applicable codes. Proper grounding is required for safety.

WARNINGS:

- Main applications include for use in high bay and other suitable light fixtures.
- Operating temperature: -30°C to 60°C (-22°F to 140°F).
- These LED Lamps require all ballasts, capacitors, and ignitors to be bypassed or removed. Do not operate lamps on
 existing ballasts.
- . Do not use with standard dimmers.
- · This device is not intended for use with emergency exits.
- For use in enclosed fixtures and minimum lamp compartment dimensions of: 13.78 in (L) x 13.78 in (W).
- · Before installation make certain the AC power to the fixture is off.
- Risk of fire or electric shock. LED Retrofit lamp installation requires knowledge of luminaires electrical systems. If not qualified, do not attempt installation. Contact a qualified electrician.
- Do not make or alter any open holes in an enclosure of wiring or electrical components during kit installation.
- To prevent wiring damage or abrasion, do not expose wiring to edges of sheet metal or other sharp objects.
- Risk of fire or electric shock. Install this kit only in luminaires that have the construction features and dimensions shown in
 the photographs or drawings and where the input rating of the retrofit kit does not exceed the input rating of the
 luminaire.
- THE RETROFIT KIT IS ACCEPTED AS A COMPONENT OF A LUMINAIRE WHERE THE SUITABILITY OF THE COMBINATION SHALL BE DETERMINED BY AUTHORITIES HAVING JURISDICTION.PRODUCT MUST BE INSTALLED BY A QUALIFIED ELECTRICIAN IN ACCORDANCE WITH THE APPLICABLE AND APPROPRIATE ELECTRICAL CODES.
 THE INSTALLATION GUIDE DOES NOT SUPERSEDE LOCAL OR NATIONAL REGULATIONS FOR ELECTRICAL INSTALLATIONS.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -Reorient or relocate the receiving antenna.
- —Increase the separation between the equipment and receiver.
- —Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- —Consult the dealer or an experienced radio/TV technician for help.


INSTRUCTIONS

FIFI D ADJUSTABLE HIGH BAY




RAB Lighting is committed to creating high-quality, affordable, well-designed and energy-efficient LED lighting and controls that make it easy for electricians to install and end users to save energy. We'd love to hear your comments. Please call the Marketing Department at 888-RAB-1000 or email: marketing@rablighting.com

INSTALLATION INSTRUCTION



SELECTABILITY Power and CCT Selectable




Model Number	Power Selectable	CCT Selectable
HIDFA-205S-EX39-8CCT-BYP	135W	3000K
	165W	4000K
	205W	5000K


INSTRUCTIONS FIELD ADJUSTABLE HIGH BAY




RAB Lighting is committed to creating high-quality, affordable, well-designed and energy-efficient LED lighting and controls that make it easy for electricians to install and end users to save energy. We'd love to hear your comments. Please call the Marketing Department at 888-RAB-1000 or email: marketing@rablighting.com

LAMP INSTALLATION







Step:1

Turn off the power before installation.
As shown in Figure 1
Remove the old Ballast, Capacitor and Ignitor (if existing).

Step:2

As shown in Figure 2
Make sure the alternating current wires
connect to the socket directly.
(Reattach or replace ground lead if one is needed).

Step:3

Select power and color temperature (CCT) of new LED replacement lamp before installation using the dip switch located on the lamp.

Step:4

As shown in Figure 3
Screw the LED lamp into the corresponding socket.
Attach retrofit label to luminaire.

Securely fasten the ground wire to the main body structure. If the wire is damaged in any way it should be replaced. (Do not use existing burnt out wire). If needed, the replacement ground wire must be 1.0mm in size and insulated from heat.

